



Add a Tee and 1" pex male. Push purge valve out to end of Tee

OWB Return

Baseboard circ pump

OWB Supply

Rotate existing Tee and upgrade to 1". This will enter bottom of boiler