




Instructions

FISHER FIREPLACE INSERT

BLOWER



Assembly

1. Attach blower fan housing to blower air duct - 2 screws.

Installation

1. Position beneath ash fender of Fireplace Insert with fan housing extending to right front of Insert. Left edge of blower air duct reaches center of Insert air intake.
2. Loosen 2 tab screws. Slide tab up and hook beneath extension lip of ash fender channel. Tighten screws.

Operation

1. Single speed, on/off switch located on blower cord.

pdfMachine

Is a pdf writer that produces quality PDF files with ease!

Produce quality PDF files in seconds and preserve the integrity of your original documents. Compatible across nearly all Windows platforms, if you can print from a windows application you can use pdfMachine.

Get yours now!