

METHODS OF RUNNING COMBUSTION AIR DUCTS FOR ENERGY SAVER SYSTEM

THE FIRST ELBOW MUST POINT DOWN

FIRST ELBOW MUST POINT DOWN. COMBUSTION AIR INLETS MUST BE BELOW THIS LEVEL. AIR DUCTS CANNOT GO UPWARD.

